

Monthly Programme Report
The Cochin College BMC

Institution Name: **The Cochin College**

BMC Code: **ERM/2022/29**

Programme Title: **Effect of Water Hyacinth infestation on the Physicochemical parameters of canal water in Karumalloor, Aluva, Kerala, India**

Program Category: Studies/Research Projects	Activity Type: Action Program	No. of participants: 20
Planned Date: 23-01-2024	Renewed date: -	Program Date: 31-03-2024
Budgeted Amount: Rs 300/-	Total expenditure: Rs 300/-	Balance: Rs 0/-

Brief Report

Water hyacinth infested canal in Karumalloor, Aluva was the sampling location. Sampling was done before and after the removal of water hyacinth during January and February 2024. Samples were collected 1-2 week after the removal of water hyacinth, this was done to determine the difference in physico-chemical and microbial parameters of the water sample due to water hyacinth infestation. Sampling was done at 3 points (close to canal wall, 100 meters away from the wall and from the center of the canal) in selected location. All the parameters, except microbial, listed below were analyzed for water samples from the 3 points and the mean/average of the three points were used to compare the effect of water hyacinth removal.

METHODOLOGY

Sampling Location: Water hyacinth infested canal in Karumalloor, Aluva was the sampling location. Sampling was done before and after the removal of water hyacinth during January and February 2024. Samples were collected 1-2 week after the removal of water hyacinth, this was done to determine the difference in physico-chemical and microbial parameters of the water sample due to water hyacinth infestation. Sampling was done at 3 points (close to canal wall, 100 meters away from the wall and from the center of the canal) in selected location. All the parameters, except microbial, listed below were analyzed for water samples from the 3 points and the mean/average of the three points were used to compare the effect of water hyacinth removal.

Figure1 – Map showing the sampling location

1. ESTIMATION OF DISSOLVED OXYGEN

Winkler's method is used for the estimation of dissolved oxygen

PRINCIPLE

In Winkler's method oxygen released from water is used to liberate iodine from potassium iodide and this iodine liberated in turn is estimated using standard Sodium thiosulphate ($\text{Na}_2\text{S}_2\text{O}_3$). When manganese sulphate (MnSO_4) is added to a sample of water followed by strong alkaline potassium iodide. Manganese hydroxide [$\text{Mn}(\text{OH})_2$] will be formed. This combines with dissolved oxygen in water. This on acidification with conc. Sulphuric acid in the presence of alkaline potassium iodide, release iodine equivalent to the amount of oxygen dissolved in the sample water. The amount of iodine liberated is estimated by titrating the sample solution against 0.01N Sodium thiosulphate.

PROCEDURE

a) Fixation of water samples

Water was taken in a BOD bottle of 250 ml immersed into the pond with minimum disturbance, taking care to avoid the formation of air bubble in it. Close the bottle with the

stopper while under water. Now remove the stopper of the water and add 2 ml of manganese sulphate solution followed by 2 ml of alkaline iodide solution into the water sample collected. Add the reagent in such a way that the tip of the pipette touches the bottom and gradually pull them upward. Close the bottle tightly with the stopper and avoid the formation of any air bubble inside. Shake the sample very well, in order to complete the formation of precipitate inside the bottle. Leave the sample undisturbed for some time so that the precipitate settles down completely.

b) Titration of water sample

Add 2 ml of conc. Sulphuric acid carefully to the precipitate and close the bottle with the stopper. Mix the content very well to dissolve the precipitate completely to form a brown coloured solution. From this pipette out 20 ml into a clean conical flask and titrate the same against 0.01N sodium thiosulphate solution from the burette and stop titration when the solution in the beaker turns pale yellow. Now add 1 ml of freshly prepared starch solution as indicator. The solutions become blue in colour. Note down the burette reading and repeat the titration for concordant value.

2. LIGHT AND DARK BOTTLE EXPERIMENT

The rate of photosynthesis or primary productivity is estimated using light and dark bottle experiment. For this two measuring cylinder of 250ml is filled with water without minimum disturbance, taking care to avoid the formation of air bubbles in it. Close the bottle with the stopper while under the water. Cover one of the bottles completely with black paper or painted completely to exclude the bottle from sunlight. And the other bottle is left as it. Now tie both the bottles and immerse the bottles into the water to some depth. Keep this arrangement undisturbed for 24 hours. After 24 hours the bottle is taken out of the water and Winkler's method is done for estimating the dissolved oxygen, so that the rate of photosynthesis can be determined.

3. ESTIMATION OF DISSOLVED CARBON DIOXIDE Dissolved carbon dioxide in the water sample is estimated using the following method **PRINCIPLE**

Carbon dioxide dissolved in water to form carbonic acid, which subsequently dissociates into H^+ and HCO_3^- . If water contains a high amount of CO_2 it becomes acidic. An acid can be titrated against a standard alkali using phenolphthalein as indicator to

Expenditure Statement

Item	Expenditure	Remarks
TA	Rs 300	
	Budgeted Amount	Rs 300
	Total Expenditure	Rs 300
	Balance Amount	Rs 0

Photographs



Results

Parameters**	Before Water Hyacinth Removal	After Water Hyacinth Removal
1 pH	6.7	7.4
2 Total Alkalinity	14 ppm in terms of calcium carbonate	16.6 ppm in terms of calcium carbonate
3 <u>Transparent</u>	Murky and opaque - hence transparency is zero	Transparent till the bottom
4 Phosphate	Absent	Absent
5 Chloride	Absent	43.3 mg/l
6 Fluoride	Absent	1mg/l
7 <u>Residual chlorine</u>	Absent	Absent
8 Iron	0	4.3 mg/l
9 Calcium hardness	20 ppm in terms of calcium carbonate	12 ppm in terms of calcium carbonate
10 Sulphate	4 ppm	2 ppm

** all these parameters were analyzed using standard Nice Water Testing Kits

Parameters	Before Water Hyacinth Removal	After Water Hyacinth Removal
Dissolved Oxygen (DO)	Not detected** 10.5mg/L	
Dissolved Carbon dioxide	5.5mg/L 1mg/L	
Net Primary productivity	Not detected** 3.6 mg.C/12hrs	
Gross Primary productivity	Not detected** 4.4 mg.C/12hrs	

TPC results

	Before Water Hyacinth Removal	After Water Hyacinth Removal
TPC	5.5 x 10 ⁶ CFU/ml	4.9 x 10 ⁶ CFU/ml